



DIRECT MOUNT STEM INSTRUCTIONS

THANK YOU FOR SELECTING A NEW NUKEPROOF DIRECT MOUNT STEM.

With proper care and installation, it will give you trouble-free, enjoyable use. In order to maximise the safe enjoyment of this product, you should read and carefully follow the following installation instructions and warnings. Failure to do so could result in unexpected wear and or failure, possibly resulting injury. We recommend having your parts fitted by a qualified bicycle mechanic. Nukeproof assumes no responsibility for malfunction or injury due to faulty installation.

TOOLS REQUIRED:

- 5mm Allen Key

DIRECT MOUNT STEM INSTALLATION INSTRUCTIONS:

1. Remove all bolts and other parts from the stem;
2. Centre the clamp over the centre section of the handlebar and rotate the bars as desired in the clamp;
3. Tighten the clamp bolts to secure the bars in the stem. These bolts should be lubricated with grease and tightened to a maximum 5Nm torque;
4. Using one hand, position the stem over the top crown aligning the direct mount bolt holes and with the other hand insert the bolts individually and tighten. These bolts should be lubricated with grease and tightened to a maximum of 10Nm torque;
5. Check for proper adjustment before each ride.

"LIMITED WARRANTY"

Nukeproof warrants this product to be free from defects in materials and workmanship for a two-year period from the date of original retail purchase. This warranty is extended only to the original owner of the product. Proof of purchase is required for any warranty service, so be sure to keep your receipt.

For full warranty terms and conditions visit <http://nukeproof.com/warranty/>