

# **NUKEPROOF**

## HOW TO FIT YOUR NUKEPROOF HORIZON MUDGUARD

### TOOLS REQUIRED

- Mudguard
- Cable ties
- Snips or scissors



### STRIP



1. Thread the cable ties through your mudguard as per photo.



2. Take the mudguard to your bike and set in place.



3. Loosely tighten all cable ties but leave enough room for movement.



4. Fully tighten the two centre cable ties positioning the mudguard in the centre of the arch.





5. Fully tighten the outer cable ties against the fork legs.



6. Rotate the cable tie so the locking mechanism is out of sight.



7. Trim the excess plastic from the cable tie.



8. Check around the mudguard/tyre to ensure that the wheel is free to move with no obstruction.



9. Your mudguard is fitted so you are ready to ride.