

NUKEPROOF

HOW TO FIT THE NUKEPROOF BOLTED ACCESSORY STRAP

For this guide we have used a 2021 Nukeproof Mega which has the mounting holes on the underside of the top tube.

We will use the long strap to hold a 29" tube, Lifeline Hybrid pump, Lifeline 25g co2 cartridge and a Nukeproof tubeless repair kit. If you want to carry less kit you can use the shorter strap. The shortest strap will be used to hold a 25g co2 cartridge on our Horizon carbon bottle cage.

BOLTED ACCESSORY STRAP FITTING



1. Get your accessory strap and the parts which you want to carry.



2. Thread the strap through the backplate. **Note:** The rubber side should be facing the same way as the Nukeproof logo on the backplate.



3. Use a 3mm hex key to remove the bolts on the underside of the top tube.



4. Put the plate up to the frame and then reinsert bolts.



5. Tighten bolts to secure.



6. Put in your accessories and tighten strap.

STRAP ON HORIZON CARBON BOTTLE CAGE



7. Get the shortest strap ready.



8. Thread through the slots on the Horizon carbon bottle cage.



9. Get a 25g co2 cartridge and tighten in the strap. This could also be used to carry a small diameter pump.

You are now ready to ride!