

## HOW TO FIT YOUR NUKEPROOF BOTTLE CAGE

### ITEMS REQUIRED

---

- 4mm hex key
- Bottle cage
- Water bottle



### STEP BY STEP INSTRUCTIONS

---



1. Undo the bottle cage bolts in your frame.



2. Unscrew the rubber caps holding the bolts in your Nukeproof bottle cage.



3. Put the bottle cage on your frame and insert both bolts.



4. Slide the cage to the desired position and tighten bolts. Your Nukeproof cage has 40mm of adjustment.



5. Insert water bottle and check it can be inserted & removed. Also ensure cage is tight.



6. On a full suspension frame, it can be worth "bottoming out" the shock to ensure that the cage or bottle is not in the way as the frame goes through its travel.

Your cage is now fitted, go ride!