


## CHAIN REACTION CYCLES PRO BIKE BAG INSTRUCTIONS




1 Remove the pedals from your bike and place them into pocket A as shown.




2 Turn your bike upside down (be careful not to damage your saddle or scratch your controls or bars).




3 Remove the wheels and set them aside for now.




4A Select an appropriate CPI and fit these in place of your hubs using QR levers or bolt through axles as required to fix them in place as you would a normal wheel/hub.



5 Fit your rear wheel into the pocket in the back wall of the bag.



6A Undo the straps on the front and rear shock blocks so they are ready to accept the bike.



7A Turn your bike up the right way and position the CPI's on top of the appropriate shock block.



Adjust the position of the blocks if needed and secure the CPI's in place using the straps.




Strap your frame to the back of the bag/wheel pocket. You may also need to adjust the height of your seat so it fits into the bag. (Be sure to leave the saddle high enough so it fills all the excess space if possible. This will prevent anything from moving around).



Adjust the position of the middle shock block so it is directly under the bottom bracket. (This will prevent damage to your chainrings). Remove padding from block if needed.



Place your front wheel into the pocket on the opening flap of the bag.



Rotate stem 180°.



Remove your handlebars, wrap them in bubble wrap or similar (not included).



Strap your handlebars to the Top Tube of your frame.



Zip the bag closed.



You are now ready to go travelling with your bike!